DRAPTEC

RS6 OE+ CARBON SIDE SKIRTS / CFP-003

INSTALLATION INSTRUCTIONS:

ATTENTION: *Installation should be carried out by a professional technician who is familiar with bodywork removal and fitting. We suggest installation to be done by one of our certified installation partners.*

-For ease of installation we recommend working on a suitable car lift.

-Required time to complete the installation: 1h

-Required tools: Plastic wedge, microfiber cloth, Heat gun.

INSTALLATION PROCEDURE:

-Step 1: Remove the original skirts by heating up the upper edge of the skirt to soften the adhesive tape and simultaneously pull the skirt to the side. We recommend starting from the back with a plastic wedge. Once you pull away the first quarter of the skirt you can use the microfiber cloth to keep the tension by pressing it in between the sill and the skirt.

-Step 2: Clean the sill surface with alcohol

-Step 3: Apply primer 3M 94 on sill surface area where adhesive tape was.

-Step 4: Push the new carbon skirt into place and adjust positon horizontally.

-Step 5: Remove the VHB tape liner and press the skirt in place.